

HALE *Premiere*



861 S. Oak Park Road, Covina, CA 91724

Tel: 1-877-977-0656


Fax: 1-800-521-4712

Email: service@cozziausa.com

HALE *Premiere*

USE & CARE MANUAL

Hale Premiere Zero Gravity Recliner



AG-7150

Thank you for purchasing the AG-7150 Hale Premiere Zero Gravity Recliner. Before using your chair, please take some time to read the contents of this instruction manual, and for easy enjoyment of this product, please continue to use as a reference guide.

AG-7150

Hale Premiere Zero Gravity Recliner

TABLE OF CONTENTS

Safety Instructions	01-02
Chair Components	03
Chair Specifications	04
Chair Dimensions	05
Placing the Chair	06
Preparations Prior to Use	08
Operation Guide	09-11
Maintenance Procedure	12
Troubleshooting	13
Warranty Information	14-16
Warranty Card (Attachment)	

SAFETY INSTRUCTIONS


Please ensure that you read these safety instructions before using your AG-7150 Hale Premiere Zero Gravity Recliner.

- This chair is intended for use only as described in this manual;
- While assembling the chair components, please ensure that the chair is not connected to any power source;
- Once fully assembled and intending to use the chair, please ensure that the power plug of the chair is securely inserted into a properly fitted electrical socket;
- Unplug the chair from the electrical source when not in use or cleaning;
- If the power is cut for any reason, please ensure that the power switch of the chair is in the off position and unplug the chair's power lead from the electrical socket, in order to prevent the risk of short circuit or damage to the chair when the power is restored;
- If you notice any tear to the fabric of the chair and /or any of the chair's internal mechanisms are visible, do not use until you have contacted the Servicing Department;
- If the electrical cord of the chair is damaged or frayed, it must be replaced by either the manufacturer, the service agent or a qualified electrician;
- Please keep the chair's power cord away from external heat sources;
- Do not wind the power core around the chair itself, as this may cause damage or malfunction;
- Do not use the AG-7150 outdoors or place the chair where it may be exposed to direct sunshine for prolonged periods or place near a heater or where temperatures may reach high levels or where there is high humidity and water vapor such as bathroom;
- Do not attempt to insert any foreign objects into any part of the chair's structure;
- Any tampering with the internal components of this chair may result in electric shock or malfunction;
- Should any liquids be spilled on the chair while in operation, please terminate functioning immediately to prevent the risk of short circuiting and resume using the chair only when it is in a clean and dry condition;
- To prevent the risk of injury, do not use the AG-7150 when you yourself are wet and never attempt to plug or unplug the power source with wet hands;
- Close and continuous supervision is necessary should children or disabled persons use this chair;
- Do not operate with any of the chair's openings blocked;
- No more than one person at a time should use this chair;
- To prevent the risk of injury or damage to the chair do not attempt to sit or stand on the back rest or leg rest;
- Do not allow children or pets to play on or around the chair;
- Please consult your doctor prior to operation, if you have any doubts about using this chair or if you are pregnant, undergoing medical treatment, using a medical electronic device or are receiving

oxygen;


- If you experience pain while using this chair, stop use immediately and consult your doctor;
- Do not use other therapeutic equipment at the same time as you are using this chair;
- This product is not intended for self-treatment of any condition that should be managed by a qualified health care provider.

CHAIR COMPONENTS




Check the accessories


Pillow



Power Adaptor




Battery



CHAIR SPECIFICATIONS

Specifications		Description
Model No.		AG-7150
Rated Voltage		Input 110-120V
Rated Frequency		60Hz
Out-put		29VDC 1.8A
Rated Power Consumption		52W
Auto Timer		15 minutes
Dimensions (L x W x H)		Chair upright: 43.3" x 30.7" x 47.5"
		Chair reclined: 63" x 30.7" x 30"
		Packing carton: 45.3" x 33.5" x 25.6"
Weight	Net Weight	111 lbs
	Gross Weight	123 lbs
Maximum Load Weight		400 lbs
Required Recline Clearance		28"
Usage Condition		Environmental temperature 10°C-40°C Contrasting humidity level 30-85RH
Storage Condition		Storage temperature 20°C- 60°C Storage humidity level 30-85RH
Safety Feature		Equipped with overheating and power surge detectors


CHAIR DIMENSIONS



* Specifications are subject to change without prior notice.

PLACING THE CHAIR

- After unpacking, place the chair on a level surface.
- Allow a clearance from walls or other objects of at least 70 cms (28 inches) or more at both the front and the back of the chair to allow the chair to recline and the footrest to be extended.



Notes


- Keep the chair at least 1 meter (3ft) away from AV machines like a TV or radio.
- Do not keep the chair in a place with high humidity, like a bathroom.
- Do not keep the chair in a place where it will be exposed to direct sunshine for an extended period, or in a place near a heater where the temperature may reach high levels.

HOW TO INSTALL THE BATTERY

Your AG-7150 recliner is equipped with a battery backup system that will activate during a power failure. The backup system is powered by four 9V batteries (not included) that need to be installed into the battery box located in the rear back of the chair as the below picture demonstrates.

FOLLOW THESE STEPS TO INSTALL THE BATTERIES:

1. Unplug the power plug from the electrical outlet.
2. Open the marked battery door.
3. Install four 9V batteries into the battery box.
4. Replace the door of the battery box.



Notes:

- Always make sure the battery box is equipped with four fresh 9V batteries, since the battery backup system does not recharge itself. Fresh batteries are defined as 9V alkaline batteries that are replaced every time the battery backup system is activated during a power failure, or once a year if the battery backup system has not been activated.
- If you unplug your AG-7150 recliner for an extended period of time (more than one hour), remove the batteries from the battery box. The AG-7150 recliner will draw power from the batteries even when it is not in use.

PREPARATION PRIOR TO USE

1. Check the material on the chair.

Prior to use, be sure to check that the cover cloth or the cloth of other parts of the chair is not torn. If a tear is found, stop using the chair immediately, unplug the power source, and obtain service. If the chair is used with torn cloth, it may result in injury or electric shock.

2. Check the power cord.


Check that there is neither breakage or damage to the power adaptor. Check that the cord is not caught or placed beneath the chair.

3. How to connect the power source.

- 1) Ensure the battery box is placed with four fresh 9V batteries.
- 2) Connect the power adaptor to the chair.
- 3) Insert the power plug into an outlet.

4. Important information for attaching the remote control.

To avoid any chance of damage to the remote control cord, make sure that after you attach the remote control to the chair connection lead, you run the cord outside of the chair. DO NOT run the cord between the arm rest and back rest.




OPERATION GUIDE

Hand-Held Controller



Dial



- | | | |
|-------|--|---|
| | | RECLINE |
| | | SIT UP |
| | | FOOTREST TILT
Press & Release |
| | | HOME
Press & Hold |
| <hr/> | | |
| | | HEAT |
| | | AIR |

1. Smart Wake Up Timer

1hr 2hr 3hr

Press the optional 1 to 3 hour timer button to start smart wake-up mode.

When the time is up, the On/Off button will flash, soft air massage will begin, and the chair will bring the user back to the home position.

2. ZGR

On pressing the ZGR button, the back rest, foot rest, and seat will be automatically adjusted to preset reclining angles.

The reclining motion can be stopped by pressing either the ZGR button, the back rest recline/restore button, or the foot rest raise/restore button.

After achieving the ZGR position, you may still adjust the angles of the back rest and foot rest by pressing the relevant buttons.

3. On/Off button

On pressing the On/Off button, a light will tell you that the chair is in the idle functioning mode and you will be able to turn on a massage program. If during a massage function program you wish to suspend for any reason, please press the On/Off button and the program will cease.

4. Relax

Press this button to activate the "Relax" air massage program. It is an air massage for gentle relaxation and loosening of muscles.

5. Stretch

Press the stretch button to activate a slightly harder air massage that gives special attention to your spine by slowly stretching it at different points and releasing stress.

Note: With the air massage in action, should you wish to change the angle of the back or foot rest, the program will pause and resume automatically once the back or foot rest movement is completed.

6. Heat

Press this button to commence the heating function for the lumbar and seat region. A light will indicate that the heating function is in operation. Press the button again to cease the function. With the heating function in operation, should you wish to change the angle of the back rest or foot rest, the heating function will pause and resume automatically once the back rest or foot rest movement is completed.

7. M1 & M2

Press and hold the M1 or M2 for 2 seconds to create a new memory position.

8. Lumbar

Press the lumbar button to inflate the air lumbar, press again to hold the current air lumbar support, and press a third time to deflate the lumbar air bag.

Lumbar support will stop working if you press the air massage button, and vice versa.

Lumbar support will hold even when the chair turns off, press again or power off to end it. It takes 25 seconds for air discharge.

9. Back Rest - Recline/Raise

Press and hold this button until the back rest is at your desired angle. The angle of the seat will move automatically to match with the angle of the backrest. Movement will be stopped once you let go of the button.

When activating the back rest, the chair will not simultaneously respond to the foot rest restore/raise action, heat, and air massage functions.

10. Foot Rest - Restore/Raise

Press and hold this button until the foot rest is at your desired angle. Movement will be stopped once you let go of the button.

When activating the foot rest, the chair will not simultaneously respond to the back rest restore/raise action, heat, and air massage functions.

Automatic Timer

The chair is programmed to operate for a period of 15 minutes, after which all functions will stop and the chair will adopt an idle mode in its current position. Note that the heating function is preset to stay on for one hour. To resume use of the chair after this period, simply press your desired function button.



MAINTENANCE PROCEDURE

WARNING

Be sure to disconnect the power plug from the outlet prior to maintenance.

NOTE

Do not attempt to use benzene. Thinner alcohol, alkaline detergent, or bleaching agent for cleaning, as this may result in deformation, discoloration or cracking.

HEAD REST, BACK PAD, SEAT COVER, ARM REST, FOOT REST, PILLOW (LEATHER)

Perform daily maintenance by wiping with a soft dry cloth. When parts are badly soiled, adopt the following maintenance procedure.

1. Soak a soft cloth in diluted neutral kitchen detergent and squeeze it well. Wipe the main unit with the damp cloth in a tapping motion.
2. Soak a cloth in clean water, and squeeze it well. Wipe of the remaining detergent with the damp cloth.
3. Wipe it with a dry cloth afterwards.
 - Do not force-dry with a drier.
 - Do not force contact with vinyl products for an extended period. It may cause discoloration.

NOTES

- Leather is a natural material, so imperfections in grain, dye variations, and natural markings do not constitute a defect.
- Polyurethane foam padding tends to soften and light creases may form on the leather cover over a period of three months. These are natural occurrences and do not require any type of maintenance.
- A professional cleaner should be contacted for particular types of stains such as ink marks.

TROUBLESHOOTING

WARNING

If the trouble still persists after following the proper countermeasures, stop using the chair to avoid possible accidents. Disconnect the power plug from the outlet and consult our customer service department. Do not attempt to repair the chair, instead contact a certified technician.

Type of Troubles	Check points	Countermeasures
Operation failure	Check that the power plug is securely plugged into the outlet	Push the power plug into the outlet securely
	Check that the power adaptor is well connected to the chair	Connect the DC terminals between the chair and power adaptor
The chair stops in the middle of operation	This phenomenon is caused by the timer and is not a problem	
Impossible to recline Impossible to raise or lower the foot rest	Check that there is no obstruction	Remove the obstruction

If you continue to have problems, please read the warranty card and contact the service department.

WARRANTY INFORMATION

This chair has the following warranty:

A one year in-home service warranty and a two-year parts warranty.

Cozzia customer service will not issue Return Material Authorizations (RMAs) for products.

This chair will be either repaired by the consumer or by an in-home technician.

SERVICE AND TECHNICAL SUPPORT

Consumers may contact Cozzia's Customer Service Department at 1-877-977-0656 between 9.00 and 5.30 PST, Monday through Friday or email us at Service@cozziausa.com for warranty and service issues.

Consumers are required to provide the unit serial number and dated proof of purchase (sales receipt) when they contact the service department regarding repair.

A customer service representative will attend to most consumer inquiries, but in some cases a technical service specialist will be required to provide enhanced support.

Non warranty repair is provided on a 'per incident' basis. Customer service will verify that the unit has failed and provide instructions for repair. All applicable repairs, parts, shipping, handling, local tax and a 'per incident' fee will be charged for non-warranty repairs and support calls.

Proof of purchase (original receipt) is required for all warranty repairs and servicing.

Extended Warranties

Cozzia offers extended warranty programs to enhance ownership of products. Our extended warranty program provides a three year parts and service warranty.

Product Repairs: Many product repairs may be performed by the customer in his/her own home with parts and instructions supplied by Cozzia, such as a remote controller replacement that does not require the services of a technician.

- Floor models and Demonstration units have a pro-rated warranty period that begins the day the model is placed on the floor and connected to an electrical outlet by the retail partner. Proof of purchase is required to obtain warranty service and parts. Non-warranty parts and servicing are available at a 'per incident' charge.
- Warranty Coverage Period: Warranty coverage starts at the time the customer purchases their chair. Proof of purchase is required for all warranty repairs. The warranty time period is measured by continuous calendar days based on the seven day week.
- Field Service: The customer service department will diagnose and schedule an authorized service provider to repair the chair in the consumer's residence.
- Parts: All parts deemed necessary for repairs will be shipped to the consumer at no charge by the service department.

CONSUMER WARRANTY LIMITATIONS AND EXCLUSIONS

Warranties are only valid in the 48 contiguous United States, and are contingent upon the consumer operating the chair according to the corresponding instruction manual.

- The warranty only applies to products and does not include any accessories or enhancements;
- Field service requires pre-approval and must be performed by Cozzia's authorized field service personnel. Field service is only available in the 48 contiguous United States;

- Softening of foam and filling composites in pillows, pads and memory foam occurs naturally and does not constitute a defect under this warranty;
- Fading, wear and piling of fabric occurs naturally and does not constitute a defect under this warranty;
- Warranty do not cover any loss or damage resulting from improper installation, unauthorized repairs or modifications, improper use of the electrical/power supply, a malfunction or damage of an operating part from failure to implement the manufacturer's recommended maintenance, transportation damage, theft, abuse, misuse, neglect, vandalism, or environmental conditions (fire, flood, rust, corrosion, sand, dirt, windstorm, hail, earthquake or exposure to weather conditions), loss of use during any period that the product is at a repair facility or is otherwise awaiting parts or repair;
- Damage due to shipping and handling does not constitute a defect under this warranty;
- Under no circumstances shall Cozzia or its representatives be liable for indirect consequential or incidental damages (including damages for lost profits, business interruption, bodily injury, medical problems) ;
- Warranties are non-transferable;
- Cozzia's sole liability and the purchaser's exclusive remedy shall be for repair, or at Cozzia's option, for replacement of the defective part. Notwithstanding the above, if the replacement parts for defective materials are not available, Cozzia reserves the right to make substitutions in lieu of repair or replacement;
- All warranties begin on the date of purchase and no allowance or extension is offered for delivery and/or installation;
- Warranties do not apply to rental businesses, commercial institutions or other non-residential users.



WARRANTY REGISTRATION FORM

Product Serial Number (located on product) _____

Purchase Price _____ Model Number _____

First Name _____ Last Name _____

Address _____

City _____ State _____ Zip _____

Phone _____

Email _____

Please mail to:

COZZIA USA LLC

861 S. Oak Park Road

Covina, CA 91724

Tel: 1-877-977-0656

Fax: 1-800-521-4712